


PARAMOTORE SPECIFICO - SPECIFIC ENGINE GUARD - PARE-CARTER SPECIFIQUE
 SPEZIFISCHER STURZBÜGEL - DEFENSA DE MOTOR ESPECIFICA

BMW F800R 2009

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE



<p>1</p>  <p>PARAMOTORE ENGINE GUARD PARE-CARTER STURZBUEGEL DEFENSA DE MOTO</p> <p>Q.TY n.2(dx-sx)</p>	<p>2</p>  <p>VITE TBEI M10x85mm passo 1/50 SCREW VIS SCHRAUBE TORNILLO</p> <p>Q.TY n.2</p>	<p>3</p>  <p>VITE TBEI M8x16mm SCREW VIS SCHRAUBE TORNILLO</p> <p>Q.TY n.2</p>	<p>4</p>  <p>SUPPORTO V717 SUPPORT SUPPORT HALTERUNG SOPORTE</p> <p>Q.TY n.2</p>	<p>5</p>  <p>DISTANZIALE Ø20x8mm Foro Ø10mm, V552 SPACER ENTRETROISE DISTANZSTUECK DISTANCIADOR</p> <p>Q.TY n.3</p>	<p>6</p> <p>COMPONENTI ORIGINALI ORIGINAL PARTS PARTIES ORIGINALES ORIGINAL BAUTEILE COMPONENTES ORIGINALES</p> <p>Q.TY n.-</p>
---	---	---	---	--	---

